

FIG. 1




FIG. 2

OVERLOAD CONTROL ANALYSIS TABLE -- 300

	CALL PROCESSOR 340	CONGESTION INDICATOR 345	LAST MESSAGE SENT 350	TIMER 355
305				
310				
315				
320				

FIG. 3

400


OUTGOING
CONGESTION
EVALUATION PROCESS

FIG. 4

500




FIG. 5

CP2	0	1	-
CP3	1	0	2 minutes
CP4	0	0	-
CP5	0	0	-

TCI = 0

FIG. 6A

CP2	0	0	-
CP3	1	0	2 minutes
CP4	0	1	-
CP5	0	0	-

TCI = 0

FIG. 6B

CP5	0	0	-
CP1	0	0	-
CP2	1	0	1 minute
CP3	1	0	2 minutes

FIG. 7A

CP5	0	0	-
CP1	1	0	3 minutes
CP2	1	0	1 minute
CP3	1	0	2 minutes

FIG. 7B

CP2	0	1	-
CP3	1	0	2 minutes
CP4	1	0	2.5 minutes
CP5	1	0	1 minute

TCI = 0

FIG. 8A

CP2	0	1	-
CP3	1	0	2 minutes
CP4	1	0	2.5 minutes
CP5	1	0	1 minute

TCI = 0

FIG. 8B